Safety Switches

Product Overview

- Used to open or close a circuit
- Non-fusible safety switches provide a means to manually connect or disconnect the load from the source
- Fusible safety switches provide a means to manually open and close a circuit and provide overcurrent protection by means of installed fuses
- Fusible switches certified for use as service entrance equipment (unless noted)
- Also commonly referred to as a disconnect switch or disconnect

Ctondord

- Available from 30-1200A
- All Padlockable
- Horsepower rated
- 100% load break rated (unless noted)
- Non-Fusible switches are 100% continuous duty rated and fusible switches are 80% continuous duty rated per CSA C22.2 No.4

Standards and Certifications

- C22.2 No.4 File #69743
- C22.2 No.14 (Enclosed Rotary) File #162136
- Det Norske Veritas
- ISO 9001:2008
- CSA certified Class I, Div, 1 & 2, Groups B, C & D; Class II, Div 1 & 2, Groups E, G & F; Class III, Div 1 & 2, Zone 1, IIB + H2 for NEMA 7/9.
- Seismic qualified (UBC and CBC) for Heavy Duty 30-800A
- ISO 1400



Fuse Clips/Class

Adaptable to Accept the Following Fuse Class


Safety Switch Type	Standard Fuse Class Clips Supplied with Switch	R	J	т
AC Disconnect	Н	_	_	_
General Duty	Н	30A-600A	400-600A	400-600A
Heavy Duty	H 30-600A L 800-1200A	30A-600A	240V-100-600A 600V-30-600A	200A-800A 1200A
Heavy Duty 6 Pole	Н	30A-200A	60A-200A	200A
Double Throw	H 30-200A T 240V-600A-1200A T 600V-400A-800A L 600V-1200A	30A-400A	240V-200A Only 600V-200A-400A	240V-600A-1200A 600V-400A-1200A (Standard)
Enviroline All Stainless & Window	Same as Heavy Duty	Same as Heavy Duty		Same as Heavy Duty
Receptacle (Pin & Sleeve)	Н	30A-100A	60A-100A	_
Solar	R	30A - 600A	_	_

Note: Refer to specific switch technical data page for field adaptation notes.

Safety Switches

Catalogue Number Selection

Safety Switch



Notes

- O Always verify the number of poles and wires required since catalogue numbers may appear in multiple tables.
- ② See Pages 12 through 14 for additional Flex Centre options.

This table is intended for use in breaking down existing catalogue numbers. It is not intended for building new catalogue numbers.

