



## 1/2" DRIVE DEEP SOCKETS - 6 POINT

- ▶ Proto® 6 Point Sockets are ideal for use on stubborn or damaged fasteners, and also on fasteners made from soft materials.
- ▶ TorquePlus™ features apply.



Product #	Size (in) (A)	Nut End Outside Dia. (in) (B)	Drive End Outside Dia. (in) (C)	Nut Depth (in) (D)	Bolt Clearance Depth (in) (E)	Overall Length (in) (L)	Weight (lbs)
J5312H	3/8	9/16	7/8	1/4	2-39/64	3-1/4	0.30
J5314H	7/16	9/16	7/8	23/64	2-39/64	3-1/4	0.30
J5316H	1/2	47/64	55/64	25/32	2-39/64	3-1/4	0.31
J5318H	9/16	13/16	27/32	7/8	2-39/64	3-1/4	0.31
J5320H	5/8	7/8	7/8	1-3/16	2-39/64	3-1/4	0.31
J5322H	11/16	31/32	31/32	1-3/16	2-39/64	3-1/4	0.33
J5324H	3/4	1-3/64	1-3/64	1-3/16	2-39/64	3-1/4	0.40
J5326H	13/16	1-1/8	1-1/8	1-3/16	2-39/64	3-1/4	0.43
J5328H	7/8	1-11/64	1-11/64	1-3/16	2-39/64	3-1/4	0.54
J5330H	15/16	1-1/4	1-1/4	1-3/16	2-39/64	3-1/4	0.65
J5332H	1	1-21/64	1-21/64	1-3/16	2-39/64	3-1/4	0.71
J5334H	1-1/16	1-7/16	1-7/16	1-3/16	2-1/4	3-1/4	0.72
J5336H	1-1/8	1-1/2	1-1/2	1	2-1/4	3-1/4	0.74
J5338H	1-3/16	1-35/64	1-35/64	1-3/32	2-1/4	3-1/4	0.85
J5340H	1-1/4	1-19/32	1-19/32	1-3/16	2-1/4	3-1/4	1.02
J5342H	1-5/16	1-7/8	1-5/8	27/32	2-19/64	3-1/2	1.06
J5344H	1-3/8	1-7/8	1-5/8	29/32	2-1/4	3-1/2	1.23
J5346H	1-7/16	2-1/16	1-5/8	61/64	2-1/4	3-1/2	1.27
J5348H	1-1/2	2	1-5/8	1	2-1/4	3-1/2	1.58



ASME B107.1

## 1/2" DRIVE SOCKETS - 8 POINT

Product #	Size (in) (A)	Nut End Outside Dia. (in) (B)	Drive End Outside Dia. (in) (C)	Nut Depth (in) (D)	Bolt Clearance Depth (in) (E)	Overall Length (in) (L)	Weight (lbs)
J5412S	3/8	45/64	55/64	1/4	1-1/64	1-7/16	0.11
J5414S	7/16	51/64	51/64	5/16	1-1/8	1-7/16	0.11
J5416S	1/2	59/64	59/64	11/32	1-3/32	1-7/16	0.11
J5418S	9/16	1	1	3/8	1-1/64	1-1/2	0.13
J5420S	5/8	1-5/64	1-5/64	37/64	1-3/32	1-1/2	0.14
J5422S	11/16	1-11/64	1-11/64	13/32	1-1/64	1-1/2	0.15
J5424S	3/4	1-15/64	1-15/64	29/64	1-1/16	1-1/2	0.18
J5426S	13/16	1-23/64	1-23/64	27/32	1-5/32	1-5/8	0.23
J5428S	7/8	1-1/2	1-1/2	27/32	1-1/8	1-5/8	0.51
J5432S	1	1-11/16	1-11/16	3/4	11/16	1-3/4	0.80



ASME B107.1