REMODELER SCREW-IN SYSTEM INSTALLATION INSTRUCTIONS



Order code	Description	Diameter (in.)	Volts	Socket
63232	RF4in/REMOD/IC/E26/STD	4	120	E26

IMPORTANT: READ ALL INSTRUCTIONS BEFORE THE INSTALLATION.

WARNING: Risk of fire or electric shock. The installation should be performed only by a qualified electrician in accordance with the National Electrical Code and relevant local codes. This product must be installed in full accordance with applicable electrical and building codes.

TO PREVENT ELECTRICAL SHOCK, MAKE SURE TO TURN OFF MAINPOWER SWITCH PRIOR TO THE INSTALLATION.

INSTALLATION

- 1. Determine the position of the fixture and cut an opening using a mounting plate of appropriate diameter.
- 2. Open the junction box and pull the wires out for easy access. Install the flexible armored cable and fitting (not supplied) onto the junction box. Make the electrical connections using the wire to wire connectors supplied, and then replace the cover.
- 3. Insert housing onto the opening until the can is flush with ceiling.
- 4. Secure the housing into position using the integrated screws-in mounting system inside the can. (Can easily be unscrewed to remove the can and reach inside the ceiling if necessary, without damaging the ceiling.)

 5. Insert the lamp (not supplied) into the socket and close the fixture using a trim adapted to your lighting needs.





