
Nuheat Floor Heating Systems

MatSense Pro Electrical Fault Indicator

MatSense Pro

Our electrical fault indicator is a device that simultaneously monitors the hot, neutral and ground wires during your Nuheat installation. Use an electric fault indicator to ensure a correct Nuheat installation every time.



The MatSense Pro will set off a distinct alarm when:

- the sensor finds an open circuit
- the sensor detects a short circuit

The MatSense Pro is the installer's safeguard to ensure homeowners that their Nuheat Floor Heating System is installed correctly every time.

Simply connect the conductor wires and ground wires to the MatSense Pro and turn it on.

The MatSense Pro is available for sale at all Nuheat Authorized Distributor locations. For a location near you, please log onto www.nuheat.com and click "Where to buy" or simply call 1 (800) 778-9276.

Using the MatSense Pro DOES NOT replace the need to conduct insulation or resistance tests of Nuheat Mat prior, during and after the installation. For more information on installation please visit www.nuheat.com.

NOTE: Nuheat Mat is repairable if damaged. If Nuheat Mat is damaged, please contact Nuheat Customer Care at 1 (800) 778-9276.

