










Push Button Units and Indicator Lights

3SB3, Components for Actuators and Indicators, 22 mm

Contact blocks and lamp holders

Version	Diagram	Operating travel <input type="checkbox"/> Contact closed <input type="checkbox"/> Contact open	DT	Solder pin connections 	PS
				Order No.	



Contact blocks for use on printed circuit boards

 3SB34 11-0B	Contact blocks with one contact Mounting depth 44 mm 1 NO		 <small>NSD0_00015</small>	3SB34 11-0B	1 unit
	1 NC	 	 <small>NSD0_00017</small>	3SB34 11-0C	1 unit
 3SB34 11-1A	Wedge base lamp holders W2 x 4.6 d Mounting depth: 44 mm Without lamp	 <small>NSD0_00003</small>		3SB34 11-1A	1 unit


⊕ Positive opening according to IEC 60947-5-1, Appendix K.

Version	DT	Order No.	PS
---------	----	-----------	----


Holders for 3 contact blocks, for front panel mounting

 3SB39 01-0AB	Holders for push buttons and switches¹⁾ for snapping on 3 blocks (for illuminated push buttons and illuminated selector switches the holder is included in the scope of supply)	3SB39 01-0AB	20 units
 3SB39 01-0AC	Holders for selector switches, key-operated switches and twin push buttons With pressure plate for actuating the central contact block of 3 contact blocks	3SB39 01-0AC	10 units

Pressure plates for use on printed circuit boards

 3SB39 01-0AW	Pressure plates for selector switches and key-operated switches For actuating the central contact block of 3 contact blocks	3SB39 01-0AW	10 units
---	---	---------------------	----------

Accessories for printed circuit boards

 3SB39 01-0AA	Holders for printed circuit boards for mounting the command devices on the printed circuit board (screw is included in the scope of supply)	3SB39 01-0AA	10 units
---	--	---------------------	----------

¹⁾ Holder also for mushroom push button and push-pull button.