

## Jl RT1 Thermal Overloads (for use with CL00 - CL45)

MIN	SETTING RANGE CAT		ORDER REF
	MIN	MAX	
0.16		0.26	RT1B
0.25		0.41	RT1C
0.4		0.65	RT1D
0.65		1.1	RT1F
1		1.5	RT1G
1.3		1.9	RT1H
1.8		2.7	RT1J
2.5		4	RT1K
4		6.3	RT1L
5.5		8.5	RT1M
8		12	RT1N
10		16	RT1P
14.5		18	RT1S
17.5		22	RT1T
21		26	RT1U
25		32	RT1V
30		40	RT1W



## Jp RT2 Thermal Overloads (for use with CL05 - CL10)

11.5	15	RT2A
14.5	19	RT2B
18.5	25	RT2C
24	32	RT2D
30	43	RT2E
42	55	RT2G
54	65	RT2H
64	82	RT2J
78	97	RT2L
90	110	RT2M

## Jk Electronic Overloads

0.1	0.5A
0.4	2A
1	5A
1.6	8A
6.4	32A
9	45A
15	75A
22	110A
30	150A



## Jy Remote Electrical Reset

DESCRIPTION	CAT REF	ORDER CODES - COIL VOLTAGES			
		24V	110V	230V	415V
Remote Electrical Reset AC/DC	RTXRR•	113662	113664	<b>113665</b>	<b>113666</b>

**For use with RT RANGE**



## Jj Accessories for Thermal Overload Relays

DESCRIPTION	CAT REF	ORDER CODE
Base for separate mounting of the Overload Relay on 35mm Din Rail	For use with RT1	RTXP <b>105170</b>
	For use with RT2	RT2XP <b>113764</b>
Setting range cover protection	For use with RT Range	RTX3 113762

