

Accessories

Auxiliary Contacts

Side-Mount Auxiliary Contacts



34

Can be fitted on the right side of manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT) and can be combined with XTPAXSATR... and XTPAXFA... trip indicating auxiliary contact.

Table 34-150. Side-Mount Auxiliary Contacts

Contact Configuration	Contact Sequence	Screw Terminals		Spring Cage Terminals		Price U.S. \$ ①
		Pkg. Qty.	Catalog Number	Pkg. Qty.	Catalog Number	
1NO-1NC		5	XTPAXSA11	5	XTPAXSAC11	
1NO-2NC		5	XTPAXSA12	—	—	
2NO-1NC		5	XTPAXSA21	—	—	

① Orders must be placed in multiples of package quantity listed.

Front-Mount Auxiliary Contacts



Can be fitted to manual motor protectors (XTPB, XTPR, XTPM) and manual transformer protectors (XTPT). 45 mm (XTPR...B and XTPB) or 55 mm (XTPR...D) widths of manual motor protectors remain unchanged.

Table 34-151. Front-Mount Auxiliary Contacts

Contact Configuration	Contact Sequence	Screw Terminals		Spring Cage Terminals		Price U.S. \$ ②
		Pkg. Qty.	Catalog Number	Pkg. Qty.	Catalog Number	
1NO-1NC		5	XTPAXFA11	—	—	
1NO-0NC		5	XTPAXFA10	5	XTPAXFAC10	
0NO-1NC		—	—	5	XTPAXFAC01	

② Orders must be placed in multiples of package quantity listed.

Discount Symbol **1CD7**