


## Motor Starter Protectors/Circuit Breakers

### SIRIUS 3RV2 Motor Starter Protectors/Circuit Breakers up to 80 A Accessories

#### Busbar accessories

Version	For motor starter protectors/ circuit breakers	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
---------	---	----	-------------	-----------------	-------------------------	-----	----

#### Covers for connection tags

 3RV1915-6AB	Touch protection for empty positions	S00, S0	▶	<b>3RV1915-6AB</b>	1	10 units	41E
		S2	▶	<b>3RV1935-6A</b>	1	5 units	41E

#### Busbar adapters



For motor starter protectors/ circuit breakers	Rated current	Connecting cable	Adapter length	Adapter width	Rated voltage	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
---	---------------	---------------------	-------------------	------------------	---------------	----	-------------	-----------------	-------------------------	-----	----

Size	A	AWG	mm	mm	V						
------	---	-----	----	----	---	--	--	--	--	--	--

#### Busbar adapters for 60 mm systems

For flat copper profiles according to DIN 46433  
Width: 12 mm and 30 mm  
Thickness: 5 mm and 10 mm  
also for T and double-T special profiles

- For motor starter protectors/circuit breakers with screw terminals

S00, S0	25	12	200	45	690	▶	<b>8US1251-5DS10</b>		1	1 unit	140
S0	32	10	260	45	690	▶	<b>8US1251-5NT10</b>		1	1 unit	140
S2	80	4	200	55	690	<b>NEW</b> A	<b>8US1261-5MS13</b>		1	1 unit	140
S2	80	4	260	55	690	<b>NEW</b> A	<b>8US1261-6MT10</b>		1	1 unit	140
S2 <sup>1)</sup>	80	4	260	118	690	<b>NEW</b> A	<b>8US1211-6MT10</b>		1	1 unit	140

- For motor starter protectors/circuit breakers with spring-type terminals

S00, S0	25	12	200	45	690	▶	<b>8US1251-5DS11</b>		1	1 unit	140
S00, S0	25	12	260	45	690	▶	<b>8US1251-5DT11</b>		1	1 unit	140
S0	32	10	260	45	690	▶	<b>8US1251-5NT11</b>		1	1 unit	140

#### Accessories

<b>Device holders</b>	--	--	200	45	--	▶	<b>8US1250-5AS10</b>		1	1 unit	140
For lateral mounting to busbar adapters	--	--	260	45	--	▶	<b>8US1250-5AT10</b>		1	1 unit	140
<b>Side modules</b>	--	--	200	9	--	A	<b>8US1998-2BJ10</b>		1	10 units	140
For widening of busbar adapters											
<b>Spacers</b>	--	--	--	--	--	▶	<b>8US1998-1BA10</b>		1	50 units	140
For fixing the load feeder onto the busbar adapter											
<b>Vibration and shock kits</b>											
For high vibration and shock loads											
S00/S0	--	--	--	--	--	▶	<b>8US1998-1CA10</b>		1	2 units	140
S2	--	--	--	--	--	<b>NEW</b> A	<b>8US1998-1DA10</b>	<b>20.40</b>	1	1 unit	140

<sup>1)</sup> For the assembly of feeders for reversing starters comprising a motor starter protector and two contactors.

For additional busbar adapters, see [Catalog LV 10 "Low-Voltage Power Distribution and Electrical Installation Technology"](#).