

#### Product Selection

##### When Ordering, Specify

- Catalog number of basic relay with 120/60, 110/50 AC coil from AR/ARD Relays table.
- If a coil voltage other than listed is required, select the suffix code from the Coil Voltage table below and substitute it for the last letter in the catalog number. Example: AR64**V** for a 110/60 AC coil.

3

#### AR/ARD Relays



#### AR/ARD Relays

Number of Poles	Contact			AR 600 Vac Relays 120/60, 110/50 AC Coil	ARD 600 Vdc Relays 120 DC Coil
	NO	NC	Blank Cavities	Catalog Number	Catalog Number
4	0	0	4	<b>AR4A</b>	<b>ARD4S</b>
	2	0	2	<b>AR420A</b>	<b>ARD420S</b>
	4	0	0	<b>AR440A</b>	<b>ARD440S</b>
6	0	0	6	<b>AR6A</b>	<b>ARD6S</b>
	4	0	2	<b>AR640A</b>	—
	6	0	0	<b>AR660A</b>	<b>ARD660S</b>
8 <sup>①</sup>	6	0	2	<b>AR860A</b>	<b>ARD860S</b> <sup>②</sup>
	8	0	0	<b>AR880A</b>	<b>ARD880S</b>
10 <sup>①</sup>	10	0	0	<b>AR10100A</b>	<b>ARD10100S</b>

#### Coil Voltage

AR Coils			ARD Coils	
Volts AC	Hz	Suffix Code	Volts DC	Suffix Code
12	60	<b>F</b>	12	<b>D</b>
24	60	<b>I</b>	24	<b>L</b>
48	60	<b>G</b>	48	<b>M</b>
110	60	<b>V</b>	95	<b>B</b>
110/120	50/60	<b>A</b>	120	<b>S</b>
208	60	<b>B</b>	130	<b>U</b>
220/240	50/60	<b>W</b>	240	<b>T</b>
277	60	<b>C</b>		
380/440	50/60	<b>H</b>		
440/480	50/60	<b>X</b>		
550	60	<b>D</b>		
550/600	50/60	<b>E</b>		

#### Contact Cartridges—600 V

Terminal Type	Standard Contact Cartridge Catalog Number <sup>③</sup>	Overlap Contact Cartridge Catalog Number <sup>④</sup>
<b>AC Cartridges</b>		
With clamp terminals	<b>ARC</b>	<b>AROC</b>
With screw terminals	<b>ARCR</b>	<b>AROCR</b>
<b>DC Cartridges</b>		
With clamp terminals	<b>ARDC</b>	<b>ARDOC</b>
With screw terminals	<b>ARDCR</b>	<b>ARDOCR</b>

##### Notes

- ① Will not accept top-mounted latch or timers.
- ② Contact Customer Support Center for availability.
- ③ Standard cartridges are sold in cartons of four cartridges. Catalog number is for single cartridge.
- ④ Overlap contact cartridges are sold in sets of two cartridges. Catalog number is for sets of two.