



**Fuse reducers for Class J fuses:
LPJ, DFJ, JKS**

Catalog numbers

Catalog numbers (pair) reducer No.	Fuse amp size range	Equipment/fuse block amp size
J-63	1-30	60
J-13	1-30	100
J-16	35-60	100
J-26	35-60	200†
J-21	70-100	200†
J-41	70-100	400†
J-42	110-200	400†
J-62	110-200	600†
J-64	225-400	600†

†Not for bolt-on applications.

**Fuse reducers for Class R fuses:
FRN-R, LPN-RK, FRS-R, LPS-RK
KTN-R, KTS-R**

UL Listed File E12853

Catalog numbers

Catalog numbers (pairs)

Voltages		Fuse amp size range	Equipment/fuse block amp size
250V	600V		
NO.263-R	NO.663-R	1-30	60
NO.213-R	NO.216-R	1-30	100
NO.216-R	NO.616-R	35-60	100
NO.226-R	NO.626-R	35-60	200
NO.2621-R	NO.2621-R	70-100	200
NO.2641-R	NO.2641-R	70-100	400
NO.242-R	NO.642-R	110-200	400
NO.2661-R	NO.2661-R	70-100	600
NO.2662-R	NO.2662-R	110-200	600
NO.2664-R**	NO.2664-R**	225-400	600

**Single reducer only (pair not required).

**Fuse reducers for Class H and K fuses:
NON, REN, NOS, RES**

UL Listed File E12853

Catalog numbers

Catalog numbers. (pairs)		Fuse amp size range	Equipment/fuse block amp size
250V reducer	600V reducer		
NO.263	NO.663	1-30	60
NO.213	NO.216	1-30	100
NO.216	NO.616	35-60	100
NO.226	NO.626	35-60	200
NO.2621	NO.2621	70-100	200
NO.2641	NO.2641	70-100	400
NO.2642	NO.2642	110-200	400
No. 2661	NO. 2661	70-100	600
No. 2662	NO. 2662	110-200	600
No. 2664	NO. 2664	225-400	600

Data Sheet: 1118



**Dummy fuse "neutrals":
(These are not fuses)**

Catalog numbers

Catalog numbers	Fuse equivalent		
	Voltage	Dimension	Fuse amp size range
NNB	—	1 ³ / ₃₂ " x 1 ¹ / ₂ "	—
NNB-R	—	Class CC	—
NNC	—	1/4" x 1 ¹ / ₄ "	—
NTN-R-30	250	Class R/H	1-30
NTN-R-60	250	Class R/H	35-60
NTN-R-100	250	Class R/H	70-100
NTN-R-200	250	Class R/H	110-200
NTN-R-400	250	Class R/H	225-400
NTN-R-600	250	Class R/H	450-600
NTS-R-30	600	Class R/H	1-30
NTS-R-60	600	Class R/H	35-60
NTS-R-100	600	Class R/H	70-100
NTS-R-200	600	Class R/H	110-200
NTS-R-400	600	Class R/H	225-400
NTS-R-600	600	Class R/H	450-600

Accessories