

Legend Plate Holders and Inserts, Pushbuttons and Double Pushbuttons <sup>②</sup>

## M22S-ST-X



| Description  | Inscription | Catalog Number                   |
|--|-------------|----------------------------------|
| Legend plate holder, without legend plate insert, for pushbuttons        | —           | <b>M22S-ST-X</b>                 |
| Legend plate holder, without legend plate insert, for double pushbuttons | —           | <b>M22S-STDD-X</b>               |
| <b>M22-XST-GB0</b>   |             |                                  |
| Legend plate insert  | —           | <b>M22-XST</b>                   |
|  | Custom      | <b>M22-XST-ETCH</b> <sup>①</sup> |
|  | STOP        | <b>M22-XST-GB0</b>               |
|  | START       | <b>M22-XST-GB1</b>               |
|  | OFF         | <b>M22-XST-GB5</b>               |
|  | ON          | <b>M22-XST-GB6</b>               |
|  | RUN         | <b>M22-XST-GB7</b>               |
|  | FAULT       | <b>M22-XST-GB8</b>               |
|  | OFF ON      | <b>M22-XST-GB10</b>              |
|  | MAN. AUTO   | <b>M22-XST-GB11</b>              |
|  | MAN. O AUTO | <b>M22-XST-GB12</b>              |
|  | HAND AUTO   | <b>M22-XST-D11</b>               |
|  | HAND O AUTO | <b>M22-XST-D12</b>               |
|  | 1           | <b>M22-XST-X52</b>               |
|  | 2           | <b>M22-XST-X53</b>               |
|  | O I         | <b>M22-XST-X88</b>               |
|  | O - I       | <b>M22-XST-X89</b>               |
|  | I O II      | <b>M22-XST-X93</b>               |

**Notes**

<sup>①</sup> When ordering, specify inscription per catalog number suffix from the Symbols Library (see **Pages V7-T1-129 to V7-T1-136**) into the Order Notes.

For example, M22-XD-S-ETCH; Order Notes: Mark with symbol X91, Line item # \_\_.

<sup>②</sup> Legend plates are IP66 and NEMA 4X/13.

**Example**

To order a legend plate for a pushbutton with non-standard markings (FORWARD):

1. Select legend plate holder—M22S-ST-X.
2. Select legend plate insert—M22-XST-ETCH.
3. Select FORWARD from the Symbols Library, **Pages V7-T1-129 to V7-T1-136**, identified by GB15 suffix.
4. Indicate on the order form in the order notes—suffix GB15, line item # \_\_\_\_ .

**Letter Height Specifications:** ≤ five characters; letter height = 0.197 in (5 mm). > five characters; letter height = 0.118 in (3 mm).

**Text—English**

| Inscription | Catalog Number Suffix |
|-------------|-----------------------|
| STOP        | GB0                   |
| START       | GB1                   |
| CLOSE       | GB2                   |
| UP          | GB3                   |
| DOWN        | GB4                   |
| OFF         | GB5                   |
| ON          | GB6                   |
| RUN         | GB7                   |
| FAULT       | GB8                   |
| TEST        | GB9                   |
| OFF ON      | GB10                  |
| MAN. AUTO   | GB11                  |
| MAN. 0 AUTO | GB12                  |
| RESET       | GB14                  |
| FORWARD     | GB15                  |
| REVERSE     | GB16                  |
| RAISE       | GB17                  |

**Text—German**

| Inscription    | Catalog Number Suffix |
|----------------|-----------------------|
| LOWER          | GB18                  |
| LEFT           | GB19                  |
| RIGHT          | GB20                  |
| BRAKE          | GB21                  |
| HIGH           | GB22                  |
| LOW            | GB23                  |
| FAST           | GB24                  |
| SLOW           | GB25                  |
| FASTER         | GB26                  |
| SLOWER         | GB27                  |
| OPEN           | GB32                  |
| PROG           | GB62                  |
| CALL           | GB63                  |
| OCCUPIED       | GB64                  |
| BYPASS<br>0 1  | GB65                  |
| BYPASS<br>UP   | GB66                  |
| EMERGENCY-STOP | GB99                  |

| Inscription | Catalog Number Suffix |
|-------------|-----------------------|
| Halt        | D0                    |
| Start       | D1                    |
| Zu          | D2                    |
| Auf         | D3                    |
| Ab          | D4                    |
| Aus         | D5                    |
| En          | D6                    |
| Betrieb     | D7                    |
| Störung     | D8                    |
| Prüfung     | D9                    |
| Aus Ein     | D10                   |
| HAND AUTO   | D11                   |
| HAND 0 AUTO | D12                   |
| Antrieb     | D13                   |
| Entsperren  | D14                   |
| Vorwärts    | D15                   |
| Rückwärts   | D16                   |
| Heben       | D17                   |
| Senken      | D18                   |
| Links       | D19                   |
| Rechts      | D20                   |
| Bremsen     | D21                   |
| Hoch        | D22                   |
| Niedrig     | D23                   |
| Schnell     | D24                   |

| Inscription             | Catalog Number Suffix |
|-------------------------|-----------------------|
| Langsam                 | D25                   |
| HAND                    | D28                   |
| AUTO                    | D29                   |
| Einrichten              | D30                   |
| Tippen                  | D31                   |
| Öffnen                  | D32                   |
| Steuerspannung          | D33                   |
| Start<br>Automatik      | D34                   |
| Lampentest              | D35                   |
| Phasenkontrolle         | D36                   |
| Alarm                   | D37                   |
| Alarm - Reset           | D38                   |
| Sammelstörung           | D39                   |
| Quittieren              | D40                   |
| Quittierung             | D41                   |
| Steuerung<br>Ein        | D42                   |
| Steuerung<br>Aus        | D43                   |
| Störung<br>quittieren   | D44                   |
| FÜHLER<br>int. ext.     | D72                   |
| HEIZUNG<br>1 2          | D73                   |
| AUS-<br>BLASEN          | D74                   |
| SOLLWERT<br>int. ext.   | D75                   |
| Not-Aus                 | D99                   |
| Not - Aus<br>quittieren | D100                  |

**Text Size: 3 mm**—Max. eight characters in first line; 10 characters in second line; eight characters in third line.



**Text Size: 5 mm**—Max. five characters per line.

