

1" Drive Scoop Tram Wheel Sockets

- Outside diameter of socket enables it to fit between the nut and the outer rim and wheel
- One piece construction

6 Point Part No.	Size	Overall Length (in.)	Weight (Ibs.)
STW1.5	1-1/2″	9	5.4
STW1-516	1-5/16″	9	5.4
STW1-14	1-1/4″	9	5.4

Swivel Wrenches

- Great for disassembly of groove joint couplings
- Tested for 190-200 ft. pounds

12 Point Part No.	Size	Overall Length (in.)	Weight (lbs.)
RSW1	7/8" X 1-1/16"	10.50	1.8
RSW2	7/8" X 11/16"	10.50	1.8
RSW3	9/16" X 3/4"	10.50	1.8
RSW4	1-1/4" x 1-7/16"	10.50	2.0
RSW5	1-1/4" x 1-5/8"	13.75	4.0

Roofbolt Dollie with Steel Extension 1-1/8" 8 PT

Part No.	Description	Overall Length (in.)	Weight (lbs.)
RBD118L12	with 12"of cut steel	20.5	9.5
RBD118L18	with 18" of cut steel	26.5	10
RBD118L24	with 24"of cut steel	32.5	10.8
RBD118L36	with 36"of cut steel	44.5	11.5
RBD118L48	with 48"of cut steel	56.5	13

Roofbolt Dollie 1-1/8" 8 PT

Part No.	Drive	Overall Length (in.)	Weight (lbs.)
RBDR25118L	Rope Thread R25	8.5	4
RBDR28118L	Rope Thread R28	8.5	4
RBDR32118L	Rope Thread R232	8.5	4
RBDR118L	7/8" Hex	8.5	4
RBDR118L1/2	1/2" Square	8.5	4
RBDR118L3/4	3/4" Square	8.5	4

Optional Leather Holder

12" Hammer Head Miner's Adjustable Wrench

- Special wide opening of 1 3/4"
- Same maximum opening as a 15" adjustable wrench at half the weight
- 7/8" hex opening in handle can be used for pulling drill steel and accommodates 1" up to 3" Victaulic couplings
- Part No: RS-12
- Part No: RSWH-1 optional leather holder

Optional Leather Holder

12" Miner's Adjustable Wrench

- Special wide opening of 1 3/4"
- Opens the same size as a 15["] adjustable wrench at half the weight
- 7/8" hex opening in handle can be used for pulling drill steel and accomodates 1" up to 3" Victaulic couplings
- Part No: RS-12H
- Part No: RSWH-1 optional leather holder

DYWIDAG Rod Installation Tool

- Spin adapters for #6/#7/#8 DYWIDAGG
- 7/8"hex drive

Part No.	Size	Overall Length (in.)	Weight (lbs.)
DSA6	#6	9	2
DSA7	#7	9	2
DSA8	#8	9	2