
ASSEMBLY INSTRUCTIONS FOR GATE VALVE LOCK-OUT

Figure A

- 1.) Close valve and verify energy is isolated
- 2.) Cover valve handle with PSL-V lockout of corresponding size.



ASSEMBLY INSTRUCTIONS FOR GATE VALVE LOCK-OUT

Figure A

- 1.) Close valve and verify energy is isolated
- 2.) Cover valve handle with PSL-V lockout of corresponding size.




Figure B

1.) Close PSL-V lockout and install lock.





Figure B

1.) Close PSL-V lockout and install lock.



B20250 Rev.2 GMPSL-INV B20250 Rev.2 GMPSL-INV

Figure C

1.) If needed, cut the recessed section with a knife to make clearance for the valve stem.




Figure C

1.) If needed, cut the recessed section with a knife to make clearance for the valve stem.




Figure D

- 1.) For small valves using PSL-V2A Only
- 2.) Drill a hole aligned with hole created as in Figure C
- 3.) Close the lockout completely and install lock





Figure D

- 1.) For small valves using PSL-V2A Only
- 2.) Drill a hole aligned with hole created as in Figure C
- 3.) Close the lockout completely and install lock



PANDUIT®

For more information
Visit us at www.Panduit.com
Contact Customer Service by email: cs@panduit.com
Or by phone: 800-777-3300



For more information
Visit us at www.Panduit.com
Contact Customer Service by email: cs@panduit.com
Or by phone: 800-777-3300