READ AND FOLLOW ALL SAFETY INSTRUCTIONS! SAVE THESE INSTRUCTIONS AND DELIVER TO OWNER AFTER INSTALLATION

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of death, injury or property damage from fire, electric shock, cuts, abrasions, falling parts, and other hazards: Service of the equipment must be performed by qualified service personnel. Installation and maintenance must be performed by a person familiar with the construction and operation of this product and any hazards involved. All applicable codes and ordinances must be followed. Read this document before installing, servicing, or maintaining this equipment or installing a lamp. These instructions do not cover all installation, service, and maintenance situations. If your situation is not covered, or if you do not understand these instructions or additional information is required, contact Lithonia Lighting or your local Lithonia Lighting Distributor. Read and follow all warnings and instructions provided by the lamp manufacturer. **A**WARNING Before installing, servicing, or maintaining this equipment, follow these general precautions. To reduce the risk of electrocution: Make sure the equipment is properly grounded. Always de-energize the circuit and/or equipment before connecting to, disconnecting from, or servicing the equipment. To reduce the risk of fire: Keep material away that can burn from hot lamp. Make sure lamps are correctly installed. Use supply conductors with a minimum installation temperature rating as specified on equipment. To reduce the risk of personal injury from cuts, abrasions, or falling parts: Wear gloves to prevent cuts or abrasions from sharp edges when removing from carton, handling and maintaining this equipment. Do not use abrasive materials, glass cleaners or other solvents on reflector or lens. These substances may damage equipment and cause parts to eventually break and fall. Do not install a damaged fixture. •

CAUTION: Observe lamp manufacturer's recommendations and restrictions on lamp operation, including but not limited to ballast type, burning position, replacement and cycling. Use only lamps that comply with applicable ANSI standards.

NOTICE: If lamp is marke (Hg) it contains mercury. Follow disposal laws. See www.lamprecycle.org

Lithonia Lighting, a division of Acuity Brands Lighting, Inc., assumes no responsibility for claims arising out of improper or careless installation or handling of this product.

SAVE THESE INSTRUCTIONS




Lithonia Lighting Outdoor One Lithonia Way, Conyers, GA 30012 Phone: 800-279-8041 Fax: 770-918-1209 www.lithonia.com


Installation Instructions TWH INDUCTION WALL-PACKS

 tions
 Delivery - Upon receipt of fixture and accessories (packed separately) thoroughly inspect for any freight damage which should be brought to the attention of the delivery carrier. Compare the catalog description listed on the packing slip with the fixture label on the inside of the housing to be sure you have received the correct m e r - chandise.

 8"
 (20.3 cm)

 Figure 1





1. Loosen the 2 stainless steel captive screws in front housing and remove front housing from fixture. See Figure 1.


2. Mount fixture using dimensions shown in Figure 2.

3. Remove electrical component cover. Keep (2) two 10-24 screws for reinstallation.

Make supply connections (outlet box or condulet tee, not provided). Reinstall the (2) 10-24 screws and electrical component cover removed in step 3. Replace front housing.
 Tighten the 2 stainless steel captive screws. Do not overtighten. Overtightening will cause stripping and void all warranties.


6. Follow lamp manufacturer's instructions regarding lamp operation and relamping. Operating a fixture with a lamp that turns on and off, an extinguished lamp, or no lamp at all may cause damage to the components and will void all warranties.





VG - Vandal Guard - Position polycarbonate vandal guard

over prismatic glass lens. Each side of the vandal guard should have an attachment screw that matches up with a mounting hole predrilled in the fixture front housing. Thread each attachment screw into the appropriate mounting hole and tighten securely.



WG - Wire~Guard - Position wire guard over prismatic glass

lens. Each side of the wire guard should have an attachment screw that matches up with a mounting hole predrilled in the fixture front housing. Thread each attachment screw into the appropriate mounting hole and tighten securely.



Troubleshooting - If this fixture fails to operate properly, check to make sure: • The correct lamp is properly installed •The fixture is wired correctly •The lamp is not faulty • The fixture is grounded correctly •The line voltage at the fixture is correct.



Lithonia Lighting Outdoor One Lithonia Way, Conyers, GA 30012 Phone: 800-279-8041 Fax: 770-918-1209 www.lithonia.com