



**ARKTITE APR
CORD CONNECTORS
30, 60, 100 AMPS**

IF1295

**INSTALLATION &
MAINTENANCE INFORMATION**

WIRING INFORMATION

Crouse-Hinds APR Cord Connectors are intended for use with **Hard Service** cord per the National Electric Code, Article 400.

The following chart gives the number of conductors and conductor size for each APR connector:

Catalog #	No. of Conductors	Amperage	Conductor Size (AWG)
APR3253	2	30	10-8
APR3255	2	30	10-8
APR3353	3	30	10-8
APR3355	3	30	10-8
APR3363	3	30	10-8
APR3365	3	30	10-8
APR3453	4	30	10-8
APR3455	4	30	10-8
APR3463	4	30	10-8
APR3465	4	30	10-8
APR6253	2	60	8-4
APR6255	2	60	8-4
APR6353	3	60	8-4
APR6355	3	60	8-4
APR6363	3	60	8-4
APR6365	3	60	8-4
APR6453	4	60	8-4
APR6455	4	60	8-4
APR6463	4	60	8-4
APR6465	4	60	8-4
APR10255	2	100	4-2
APR10257	2	100	4-2
APR10355	3	100	4-2
APR10357	3	100	4-2
APR10365	3	100	4-2
APR10367	3	100	4-2
APR10455	4	100	4-2
APR10457	4	100	4-2
APR10465	4	100	4-2
APR10467	4	100	4-2

All statements, technical information and recommendations contained herein are based on information and tests we believe to be reliable. The accuracy or completeness thereof are not guaranteed. In accordance with Crouse-Hinds "Terms and Conditions of Sale", and since conditions of use are outside our control, the purchaser should determine the suitability of the product for his intended use and assumes all risk and liability whatsoever in connection therewith.



Crouse-Hinds

Quality from Cooper Industries

IF1295
New 6/93