



BRASS FUEL LINE HOSE BARBS

B



COUPLER
Hose Barb
To Male Pipe

PART No.	Hose I.D.	Pipe
325-3A	3/16	1/8
325-4A	1/4	1/8
325-4B	1/4	1/4
325-5A	5/16	1/8
325-5B	5/16	1/4
325-6A	3/8	1/8
325-6B	3/8	1/4
325-6C	3/8	3/8
325-10C	5/8	3/8
325-10D	5/8	1/2
325-12D	3/4	1/2



CONNECTOR
Hose Barb To
Male Inverted
Flare

PART No.	Hose I.D.	Tube Size
335-54	5/16	1/4
335-55	5/16	5/16
335-65	3/8	5/16
335-66	3/8	3/8



90° ELBOW
Hose Barb
To
Male Pipe

PART No.	Hose I.D.	Pipe
339-4A	1/4	1/8
339-5A	5/16	1/8
339-5B	5/16	1/4
339-6A	3/8	1/8
339-6B	3/8	1/4
339-10C	5/8	3/8

FOR FUEL LINE HOSE SEE PAGE 101.

STEEL COMBINATION NIPPLES AND HOSE MENDERS (NOT RECOMMENDED FOR USE WITH AIR)



COMBINATION NIPPLE
Hose Barb To
Male Pipe

PART No.	Hose I.D.	Pipe
BI-125-8D	1/2	1/2
BI-125-12E	3/4	3/4
BI-125-16H	1	1
BI-125-20J	1-1/4	1-1/4
BI-125-24K	1-1/2	1-1/2
BI-125-32M	2	2
BI-125-40N	2-1/2	2-1/2

ALSO AVAILABLE IN GALVANIZED. REPLACE PREFIX BI- WITH GI-
EXAMPLE: GI-125-24K



HOSE MENDER
Hose Barb

PART No.	Hose I.D.
BI-129-8	1/2
BI-129-12	3/4
BI-129-16	1
BI-129-20	1-1/4
BI-129-24	1-1/2

ALSO AVAILABLE IN GALVANIZED. REPLACE PREFIX BI- WITH GI-
EXAMPLE: GI-129-24

BRASS STANDARD FERRULES FBL – Ferrules Brass Long



FBL



FBS

- SIZE RANGE FROM 3/8 TO 1 INCH OUTSIDE DIAMETER
- THE PART NUMBER DESIGNATES THE OUTSIDE DIAMETER OF THE HOSE OR TUBE
- WALL THICKNESS OF THE FERRULE IS .025
- TO ORDER A FERRULE CRIMPER SEE PAGE 246

PART No.	Inside Dia. (IN.)	Ferrule Length (IN.)	Hole Size (IN.)	PART No.	Inside Dia. (IN.)	Ferrule Length (IN.)	Hole Size (IN.)	PART No.	Inside Dia. (IN.)	Ferrule Length (IN.)	Hole Size (IN.)
FBL-400	.400	23/32	.265	FBL-675	.675	31/32	.500	FBL-925	.925	31/32	.750
FBL-450	.450	23/32	.328	FBL-700	.700	31/32	.500	FBL-975	.975	31/32	.875
FBL-475	.475	23/32	.328	FBL-725	.725	31/32	.500	FBL-1000	1.000	31/32	.875
FBL-500	.500	23/32	.328	FBL-750	.750	31/32	.500	FBL-1025	1.025	31/32	.875
FBL-525	.525	23/32	.453	FBL-775	.775	31/32	.500	FBL-1100	1.100	31/32	.875
FBL-550	.550	23/32	.438	FBL-800	.800	31/32	.625	FBL-1125	1.125	31/32	.875
FBL-575	.575	31/32	.438	FBL-825	.825	31/32	.625	FBL-1150	1.150	31/32	.875
FBL-600	.600	31/32	.453	FBL-850	.850	31/32	.687	FBL-1175	1.175	55/64	.875
FBL-625	.625	31/32	.453	FBL-875	.875	31/32	.750	FBL-1275	1.275	31/32	.875
FBL-650	.650	31/32	.453	FBL-900	.900	31/32	.750	FBL-1500	1.500	31/32	.875

BRASS SHORT FERRULES FBS – Ferrules Brass Short

PART No.	Inside Dia. (IN.)	Ferrule Length (IN.)	Hole Size (IN.)	PART No.	Inside Dia. (IN.)	Ferrule Length (IN.)	Hole Size (IN.)	PART No.	Inside Dia. (IN.)	Ferrule Length (IN.)	Hole Size (IN.)
FBS-500	.500	1/2	.328	FBS-575	.575	15/32	.453	FBS-700	.700	17/32	.500
FBS-550	.550	9/16	.453	FBS-600	.600	15/32	.453				

BRASS GRIP-TITE HOSE FITTINGS

(USE WITH GRIP-TITE HOSE: SEE PAGE 105)



Male Pipe

PART No.	Hose I.D.	Pipe
725-4A	1/4	1/8
725-4B	1/4	1/4
725-4C	1/4	3/8
725-5A	5/16	1/8
725-5B	5/16	1/4
725-6A	3/8	1/8
725-6B	3/8	1/4
725-6C	3/8	3/8
725-6D	3/8	1/2
725-8B	1/2	1/4
725-8C	1/2	3/8
725-8D	1/2	1/2
725-8E	1/2	3/4
725-10C	5/8	3/8
725-10D	5/8	1/2
725-10E	5/8	3/4
725-12D	3/4	1/2
725-12E	3/4	3/4



Working Male Pipe Swivel

PART No.	Hose I.D.	Pipe
725SW-4B	1/4	1/4
725SW-6B	3/8	1/4
725SW-6C	3/8	3/8
725SW-8C	1/2	3/8
725SW-8D	1/2	1/2
725SW-12E	3/4	3/4



RIGID Female Pipe

PART No.	Hose I.D.	Tube
726-4A	1/4	1/8
726-4B	1/4	1/4
726-6B	3/8	1/4
726-6C	3/8	3/8
726-8C	1/2	3/8
726-8D	1/2	1/2
726-8E	1/2	3/4
726-12E	3/4	3/4



45° S.A.E. Male Flare

PART No.	Hose I.D.	Tube
727-44	1/4	1/4
727-45	1/4	5/16
727-66	3/8	3/8
727-88	1/2	1/2



45° S.A.E. Female Flare Swivel

PART No.	Hose I.D.	Tube
728-44	1/4	1/4
728-45	1/4	5/16
728-66	3/8	3/8
728-68	3/8	1/2
728-86	1/2	3/8
728-88	1/2	1/2
728-810	1/2	5/8
728-108	5/8	1/2
728-1010	5/8	5/8
728-1212	3/4	3/4



HOSE SPLICER

PART No.	Hose I.D.
729-4	1/4
729-5	5/16
729-6	3/8
729-8	1/2
729-10	5/8
729-12	3/4



GASKET TYPE

Female Straight Pipe Swivel

PART No.	Hose I.D.	Straight Pipe
730-4B	1/4	1/4



BALL TYPE

Female Straight Pipe Swivel

PART No.	Hose I.D.	Straight Pipe
731-4A	1/4	1/8
731-4B	1/4	1/4
731-6B	3/8	1/4
731-6C	3/8	3/8
731-8D	1/2	1/2
731-12E	3/4	3/4



RIGID Tube Shank

PART No.	Hose I.D.	Tube
732-44	1/4	1/4
732-66	3/8	3/8



45° S.A.E. Male Inverted Flare Swivel

PART No.	Hose I.D.	Tube
735-43	1/4	3/16
735-44	1/4	1/4
735-45	1/4	5/16
735-65	3/8	5/16
735-66	3/8	3/8
735-88	1/2	1/2
735-1010	5/8	5/8



45° S.A.E. Female Inverted Flare

PART No.	Hose I.D.	Tube
736-44	1/4	1/4
736-45	1/4	5/16
736-65	3/8	5/16
736-66	3/8	3/8



37° J.I.C. Male Flare

PART No.	Hose I.D.	Tube
737-44	1/4	1/4
737-66	3/8	3/8
737-88	1/2	1/2



37° J.I.C. Female Flare Swivel


PART No.	Hose I.D.	Tube
738-44	1/4	1/4
738-45	1/4	5/16
738-66	3/8	3/8
738-88	1/2	1/2
738-1010	5/8	5/8
738-1212	3/4	3/4



90° ELBOW Hose To Male Pipe

PART No.	Hose I.D.	Pipe
739-4A	1/4	1/8
739-4B	1/4	1/4
739-6B	3/8	1/4
739-6C	3/8	3/8
739-8C	1/2	3/8
739-8D	1/2	1/2
739-12E	3/4	3/4

ASSEMBLY INSTRUCTIONS



- LUBRICATE HOSE AND BARB.
- PUSH HOSE ON FITTING UNTIL SEATED UNDER PROTECTIVE CAP.
- NO CLAMPS REQUIRED WHEN USED WITH GRIP-TITE HOSE.

B