












3SB3 Pushbuttons and Indicator Lights, 22 mm

Components for Actuators and Indicators

Contact blocks and lampholders

Version	Graphic symbols	Operating travel	DT	Solder pin connections	PU (UNIT, SET, M)	PS*	PG
		<input type="checkbox"/> Contact closed <input type="checkbox"/> Contact open		Article No. Price per PU			
Contact blocks for use on printed circuit boards							
 3SB3411-0B	Contact blocks with one contact Mounting depth 44 mm						
	1 NO	 	B	3SB3411-0B	1	1 unit	41J
	1 NC	 	B	3SB3411-0C	1	1 unit	41J
 3SB3411-1A	Wedge base lampholders W2 x 4.6d Mounting depth: 44 mm Without lamp						
			B	3SB3411-1A	1	1 unit	41J

⊕ Positive opening according to IEC 60947-5-1, Appendix K.

Version	DT	Article No.	Price per PU	PU (UNIT, SET, M)	PS*	PG
Holders for 3 contact blocks, for front plate mounting						
 3SB3901-0AB		Holders for pushbuttons and switches¹⁾ For snapping on 3 blocks (for illuminated pushbuttons and illuminated selector switches the holder is included in the scope of supply)		100	20 units	41J
 3SB3901-0AC		Holders for selector switches, key-operated switches and twin pushbuttons With pressure plate for actuating the central contact block of three contact blocks ²⁾		100	10 units	41J
Pressure plates for use on printed circuit boards						
 3SB3901-0AW	B	Pressure plates for selector switches and key-operated switches For actuating the central contact block of three contact blocks ²⁾		100	10 units	41J
Accessories for printed circuit boards						
 3SB3901-0AA	B	Holders for printed circuit boards For mounting the command devices on the printed circuit board (screw is included in the scope of supply)		100	10 units	41J

¹⁾ Holder also for mushroom pushbutton and push-pull button.

²⁾ The pressure plates can be removed to meet individual requirements.