IEC Contactors and Starters

XT IEC Power Control

Frames B–C, Front (Top) Mount—Tall Version Two-Pole [®]



Conventional Thermal Current, Open at 60°C Circuit Pkg. **Screw Terminal** Contact Symbol Qty. 2 $I_{th} = I_e$, AC-1 in Amps Configuration **Catalog Number** 16 2N0 5 XTCEXFATC20 5363 5464 16 1NO-1NC 5 XTCEXFATC11 5361 5462 16 2NC 5 XTCEXFATC02 5161 5262

XTCEXFATC22

Frames B–C, Front (Top) Mount—Tall Version Four-Pole 0

Conventional Thermal Current, Open at 60°C I _{th} = I _e , AC-1 in Amps	Contact Configuration	Circuit Symbol	Pkg. Qty. [©]	Screw Terminal Catalog Number
16	2NO-2NC	53,61,71,83 -\	5	XTCEXFATC22



Frame B, Side-Mount-Single-Pole



Conventional Thermal Current, Open at 60°C I _{th} = I _e , AC-1 in Amps	Contact Configuration	Circuit Symbol	Pkg. Qty. @	Screw Terminal Catalog Number
16	1NO	53	1	XTCEXSAB10 ③
16	1NC	51	1	XTCEXSAB01 ③



Frame C, Side-Mount-Two-Pole

Conventional Thermal Current, Open at 60°C I _{th} = I _e , AC-1 in Amps	Contact Configuration	Circuit Symbol	Pkg. Qty. ®	Screw Terminal Catalog Number
10	1NO-1NC	153 <u>1</u> 61 / 154162	1	XTCEXSCC11 ③

Notes

Interlocked opposing contacts, to IEC/EN 60947-5-1 Annex L (positively driven), within the auxiliary contact modules (not NO [early make] and NC [late break] contacts) and for the built-in auxiliary contacts of the XTCE007B_-XTCE032C_. Auxiliary break contact can be used as mirror contact to IEC/EN 60947-4-1 Annex F (not NC [late break] contact).

No auxiliary contacts can be fitted between two contactors.

- ^① Front (top) mount tall version is for use with Frame B electrical wire bridges and link kits (see Page V5-T1-74) and toolless plug combination connection kits: XTCEXRLB, XTCEXSDLB, XTPAXTPCB, XTPAXTPCRB, XTPAX.
- $\ensuremath{\textcircled{0}}$ 0rders must be placed in multiples of package quantity listed.
- ③ Can be mounted to the left side of contactor only. Cannot be used in combination with front (top) mount auxiliary contacts or mechanical interlocks.