












Contact configuration	Approval mark	Connection Type	Part no. Article no.	Notes
<p>⊖ Positive opening safety function according to IEC/EN 60947-5-1 N/O = normally open contact N/C = normally closed contact</p>				
Hasp-operated safety switch LSR-.../TKG, IP65				
 -	2 N/C ⊖	 Screw terminal	LSR-S02-1-I/TKG 106848	
1 N/O	1 N/C ⊖	Screw terminal	LSR-S11-1-I/TKG 106847	
Hinge-operated switch LSR-.../TS, IP65				
 -	2 N/C ⊖	 Screw terminal	LSR-S02-1-I/TS 106852	
1 N/O	1 N/C ⊖	Screw terminal	LSR-S11-1-I/TS 106851	
Safety position switch LS-...-ZB, IP65				
 -	2 N/C ⊖	 Cage Clamp	LS-02-ZB 106817	 <p>Actuator included as standard.</p>
-	2 N/C ⊖	Screw terminal	LS-S02-ZB 106874	
1 N/O	1 N/C ⊖	Cage Clamp	LS-11-ZB 106819	
1 N/O	1 N/C ⊖	Screw terminal	LS-S11-ZB 106876	
1 N/O	1 N/C ⊖	Cage Clamp	LS-11S-ZB 106870	
1 N/O	1 N/C ⊖	Screw terminal	LS-S11S-ZB 106877	
Safety position switch LS4.../ZB, IP65				
 1 N/O	1 N/C ⊖	  Screw terminal	LS4/S11-1/I/ZB 106857	<p>Actuator can be repositioned for horizontal or vertical installation. The operating heads can be rotated manually in 90° steps to suit the specified level of actuation.</p>  <p>Actuator included as standard.</p>
1 N/O	1 N/C ⊖	Screw terminal	LS4/S11-1/IA/ZB 106858	
1 N/O	2 N/C ⊖	Screw terminal	LS4/S12-7/IB/ZB 106859	