

- 1. CUT CONDUIT/TUBING END SQUARE.
- 2. APPLY COMPRESSION NUT OVER CONDUIT/TUBING
- 3. TAPTHE FERRULE ONTO THE END OF THE CONDUIT/TUBING CONDUIT SHOULD ENGAGE FERRULE FINGERS ½" MIN. (SEE FIG 4).
- 4. POSITION SWIVEL ELBOW OR STRAIGHT BODY ONTO FERRULE AND THREAD COMPRESSION NUT INTO PLACE.
- 5. HAND TIGHTEN THE COMPRESSION NUT UNTIL SECURELY BOTTOMS OUT AGAINST THE FERRULE. TO INSURE FULL LIQUID-TIGHT GRIPPING CAPABILITY, THE GAP BETWEEN THE NUT AND THE BODY FLANGE SHOULD BE LESS THAN .055" (SEE FIG 3.).
- 6. SNAP SEALING O-RING ONTO SEAT PROVIDED FOR A LIQUID-TIGHT SEAL THROUGH ANY BOX APPLICATION.
- 7. SECURE WITH LOCKNUT OR INTO FEMALE THREAD AS REQUIRED.

Wiring Device-Kellems Hubbell Incorporated (Delaware) 185 Plains Road Milford, CT 06460-8897 (203) 882-4800

PD1859 (Page 1) PRINTED IN USA 10/01



LOOK FOR **KELLEMS®** QUALITY PRODUCTS FOR ALL YOUR WIRE MANAGEMENT NEEDS

Polytuff I	-	Flexible liquidtight nonmetallic conduit.
Polytuff II	-	Flexible liquidtight nonmetallic tubing.
Metallic Fittings	-	Insulated and noninsulated for metallic and nonmetallic flexible liquidtight conduit.
Nonmetallic Fittings	-	For nonmetallic liquidtight flexible conduit or tubing.

Recommended Knockout Holes			
Trade	Recommended		
Size	Min. to Max.		
1/2"	.859906		
3/4"	1.094 - 1.141		
1"	1.359 - 1.406		
1 ^{1/4} "	1.719 - 1.766		
11/2"	1.969 - 2.016		
2"	2.453 - 2.500		

PD1859